

Pushbutton Access and Release Devices

700 Series Pushbuttons



701 Series



709 Series

Schlage Locknetics 700 Series Entry Level Pushbutton are designed to meet commercial applications. Use to egress swinging or sliding doors that are electrically or electronically locked. 700 Series Entry Level Pushbuttons are available for single gang and narrow stile applications. The 709 model, includes backlit buttons with "PUSH TO EXIT" or Handicap Symbol to meet ADA requirements.

Benefits of Using Locknetics Pushbutton Access and Release Devices

- *Standard stainless steel*
- *Momentary action (standard)*
- *7/8" red/black mushroom button*
- *2" square illuminated button*
- *Options include LEDs, alternate action - maintained (AA)*

Pushbutton Access and Release Devices

700 Series Pushbuttons

How To Order 700 Series Pushbutton Access and Release Devices

701RD – L2

Select Model
Select Options

1. Select Model

701RD	7/8" Red Mushroom Button
701BK	7/8" Black Mushroom Button
701RD EX	5/8" Red Button - Engraved "PUSH TO EXIT"
701RD EX ILL	5/8" Red Button - Illuminated "PUSH TO EXIT"
709RD EX ILL	2" Red Square - Illuminated "PUSH TO EXIT"
709GR EX ILL	2" Green Square - Illuminated "PUSH TO EXIT"
709BLH ILL	2" Blue Square - Illuminated Handicapped Symbol

2. Select Options

L2	Two LEDs, red and green, dual voltage
AA	Alternate Action – Maintained (not available for 709 models)
NS	Narrow Stile plate (not available for 709 models)

Specifications:

701 Pushbutton

Contact Ratings:	5 amps @ 250 VAC
Wire Leads:	20 awg – 6" long

709 Pushbutton

Contact Ratings:	10 amps @ 250 VAC
Wire Leads:	20 awg – 8" long

Input requirements with LED option

Voltage:	12/24 VDC
Current Draw:	30 mA
Wire Leads:	24 awg – 6" long

Input requirements with ILL option

Voltage:	12 VDC for 709 series only
	24 VDC for 701/709 series