

Four-Door System

A One (1) ES-4MB² 4-Door, 4-Mullion Mount Reader Essential Access System Bundle (Part # ES-4MB)

B One (1) ProxCARD II 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARDII)




Six-Door System

A One (1) EL36-4MB² 4-Door, 4-Reader Elite Access System Bundle (Part # EL36-4MB)

B One (1) ACM2DB³ 2-Door, 2-Reader ACM with Reader Bundle (Part # ACM2DB); ACM mounts inside either the ES or EL standard metal enclosure

C One (1) ProxCARD II 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARDII)




Eight-Door System

A One (1) EL36-4MB² 4-Door, 4-Reader Elite Access System Bundle (Part # EL36-4MB)

B One (1) ACM4DB³ 4-Door, 4-Reader Access System Bundle (Part # ACM4DB); ACM mounts inside either the ES or EL standard metal enclosure

C One (1) ProxCARD II 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARDII)



Ten-Door System

A One (1) EL36-4MB² 4-Door, 4-Reader Elite Access System Bundle (Part # EL36-4MB)

B One (1) EXN-2MB³ 2-Door, 2-Reader Access System Expansion Bundle (Part # EXN-2MB)

C One (1) ACM4DB³ 4-Door, 4-Reader Access Control Module Bundle (Part # ACM4DB); ACM mounts inside either the ES or EL standard metal enclosure

D One (1) ProxCARD II 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARDII)



ES = eMerge Essential

EL = eMerge Elite

² Includes Four (4) 2N1 Reader HAF 125 kHz, HID, AWID and Farpointe compatible, Proximity Access Card Reader (2N1ProxHAF – Item #620-100451)

³ Includes Two (2) 2N1 Reader HAF 125 kHz, HID, AWID and Farpointe compatible, Proximity Access Card Reader (2N1ProxHAF – Item #620-100451)

To try an E3-Series eMerge system, go to: www.nortekcontrol.com/try-emerge-essential.php

For License-to-Go™ upgrades, go to: www.e3upgrade.com