

HID Activation - Paxlock

When the HID™ activation card is presented, the **green** LED will flash to indicate acceptance.

Subsequently, both the **red** and **green** LEDs will flash, in sync with a beep, to indicate the number of licences remaining on the activation card which was presented.

If the activation card has used all the licences available, the PaxLock will illuminate the **red** LED to indicate the card is empty and another activation card should be purchased.

HID Activation - Net2 Entry (Second Generation only)

When the HID™ activation card is presented, the screen will display an HID™ logo along with a check mark (see right) to indicate the acceptance.

Subsequently, the Net2 Entry panel will beep to indicate the number of licences remaining on the activation card which was present



Sales codes

HID™ Prox® 125 kHz activation card sales codes:

125-001 - US 1 Licence activation

Affected reader range sales codes:

323-110-US Proximity reader - P200

324-110-US Proximity reader - P200, Metal mount

333-110-US Proximity Reader – P38

337-400-US Net2 Entry - Standard panel, flush mount

337-405-US Net2 Entry - Standard panel, flush mount - Single door kit

337-410-US Net2 Entry - Standard panel, surface mount with rain hood

337-415-US Net2 Entry - Standard panel, surface mount with rain hood - Single door kit

337-420-US Net2 Entry - Standard panel, surface mount

337-425-US Net2 Entry - Standard panel, surface mount - Single door kit